

Reporting AVL Faults

To allow prompt repairs to any AVL faults drivers should report faults as soon as possible.

If the AVL system is not working you can call Control using the **F1 button** on the radio as shown below:



When you contact Control, please supply your **block number**, **payroll number**, and the **nature of the fault**.

Some faults such as log on faults can be rectified by Control, others need to be recorded to allow the fault to be rectified at the depot and your assistance with this matter is appreciated.